
EXHAUST 07

CONTENTS

	page
Exhaust System	07-1


EXHAUST SYSTEM

GENERAL INFORMATION	07-2	Removal & Installation - 2.4L	07-5
Description	07-2	Muffler	07-6
Operation	07-3	Removal & Installation	07-6
Specifications	07-3	Catalytic Converter	07-6
DIAGNOSIS AND TESTING	07-4	Description	07-6
Exhaust System Diagnostic Chart	07-4	Operation	07-6
ON-VEHICLE SERVICE	07-5	Removal & Installation	07-7
Exhaust Pipe Assembly	07-5		
Removal & Installation - 1.6L & 1.8L & 2.0L	07-5		


GENERAL INFORMATION

Description

1.6L & 1.8L & 2.0L Exhaust System



2.4L Exhaust System



The exhaust system provides an exit for exhaust gases and reduces engine noise by moving exhaust gases through the three-way catalytic converter, a muffler inlet pipe and a muffler. Rubber exhaust hanger insulators attach the exhaust system to the mounting hooks.

The exhaust system contains the following components:

- Catalytic converter assembly
- Muffler assembly
- Exhaust brackets with isolators bolted to the body
- Heated oxygen sensors mounted to the exhaust pipes
- Tailpipe assembly

GENERAL INFORMATION

WARNING!

Exhaust gases contain carbon monoxide which can be harmful to your health and are potentially lethal. Exhaust system leaks should be repaired immediately. Never operate the engine in enclosed areas. Failure to follow these instructions may result in personal injury or death.

Operation

In order to reduce vehicle emissions released by the engine, the catalytic converter is required to perform in all operating conditions. This reduction is especially beneficial during the cold start and warm up phases of operation, which is when a majority of the tailpipe emissions occur on today's vehicles because the catalytic converter has not yet reached its operating temperature. The exhaust system channels exhaust gases from the engine and away from the vehicle.

Specifications

Torque Specifications

DESCRIPTION	TORQUE (N·m)
Catalytic Converter Mounting Nuts	50
Exhaust Manifold Flange Bolts	49 ± 5
Muffler Mounting Nuts	50

07

DIAGNOSIS AND TESTING

Exhaust System Diagnostic Chart

CONDITION	POSSIBLE CAUSES	CORRECTION
Excessive Exhaust Noise	· Leaks at pipe joints. · Burned or blown out muffler. · Burned or rusted-out exhaust pipe. · Exhaust pipe leaking at manifold flange. · Exhaust manifold cracked or broken. · Leak between exhaust manifold and cylinder head. · Restriction in muffler or tailpipe. · Exhaust system contacting body or chassis.	· Tighten clamps to specified torque at leaking joints. · Replace muffler assembly. · Replace exhaust pipe. · Tighten connection attaching nuts. · Replace exhaust manifold. · Tighten exhaust manifold to cylinder head stud nuts or bolts. · Remove restriction, if possible. Replace muffler or tailpipe, as necessary. · Re-align exhaust system to clear surrounding components.
Leaking Exhaust Gases	· Leaks at pipe joints.	· Tighten/replace clamps at leaking joints.

ON-VEHICLE SERVICE


Exhaust Pipe Assembly

Removal & Installation - 1.6L & 1.8L & 2.0L

WARNING!

The normal operating temperature of the exhaust system is very high. Therefore, never work around, or attempt to service any part of the exhaust system until it has cooled. Special care should be taken when working near the catalytic converter. The temperature of the converter rises to a high level after a short period of engine operating time.

1. Raise and support the vehicle.
2. Remove the catalytic converter to exhaust manifold bolts (1).
(Tighten: Exhaust manifold flange bolts to 49 ± 5 N·m)



07


3. Remove all the support isolators.
4. Remove the exhaust pipe assembly.

Removal & Installation - 2.4L

WARNING!

The normal operating temperature of the exhaust system is very high. Therefore, never work around, or attempt to service any part of the exhaust system until it has cooled. Special care should be taken when working near the catalytic converter. The temperature of the converter rises to a high level after a short period of engine operating time.

1. Raise and support the vehicle.
2. Remove the catalytic converter to exhaust manifold bolts (1).
(Tighten: Exhaust manifold flange bolts to 49 ± 5 N·m)



3. Remove all the support isolators.
4. Remove the exhaust pipe assembly.


Muffler

Removal & Installation

WARNING!

The normal operating temperature of the exhaust system is very high. Therefore, never work around, or attempt to service any part of the exhaust system until it has cooled. Special care should be taken when working near the catalytic converter. The temperature of the converter rises to a high level after a short period of engine operating time.

1. Raise and support the vehicle.
2. Remove the muffler mounting nuts (1).
(Tighten: Muffler mounting nuts to 50 N·m)
3. Remove the support isolators (2).



4. Remove the muffler.
5. Clean the ends of the pipes and the muffler to ensure proper mating of all parts. Discard broken or worn isolators, rusted or overused clamps, supports, and attaching parts.
6. Installation is in the reverse order of removal.

Catalytic Converter

Description

The catalytic converter is attached to the exhaust manifold using fasteners and a gasket for sealing.

The catalytic converter plays a major role in the emission control system. The catalytic converter operates as a gas reactor. Its catalytic function is to speed the heat-producing chemical reaction of components in the exhaust gases in order to reduce air pollutants.

Operation

Catalyst operation is dependent on its ability to store and release the oxygen needed to complete the emissions-reducing chemical reactions. As a catalyst deteriorates, its ability to store oxygen is reduced. Since the catalyst's ability to store oxygen is somewhat related to proper operation, oxygen storage can be used as an indicator of catalyst performance.

CAUTION:


Unleaded gasoline must be used in order to avoid damaging the catalyst core.

Removal & Installation

WARNING!

The normal operating temperature of the exhaust system is very high. Therefore, never work around or attempt to service any part of the exhaust system until it has cooled. Special care should be taken when working near the catalytic converter. The temperature of the converter rises to a high level after a short period of engine operating time.

1. Disconnect the negative battery cable.
2. Raise and support the vehicle.
3. Remove the catalytic converter mounting nuts (1) and gaskets.
(Tighten: Catalytic converter mounting nuts to 50 N·m)
4. Remove the catalytic converter.
5. Clean the ends of the pipes to ensure proper mating of all parts. Discard broken or worn isolators, rusted or overused clamps, supports, and attaching parts.
6. Installation is in the reverse order of removal.



Itsm070001